Cushion For Wii Fit Balance Board

WI-CUSH

Our soft, comfortable balance board cover is an accessory that you do not want to be with out. The plush material feels great under your feet when standing on the balance board with or with out socks on. The balance board is made of hard unforgiving plastic, and with the use of the plush cushion you can still play all games that use the balance board, but with out your feet hurting. You can also use the cushion for games that require sitting on the balance board. The cushion is the perfect solution for how uncomfortable the balance board can be to sit on. Anytime you use the balance board, you will be glad to have the plush cushion, and if your cushion cover gets dirty, just throw it in the washing machine!

for Wii fit™ Balance Board

Features include:

- Protects surface of balance board
- Drastically increases comfort
- Will not slip off during use
- Feels great under your feet

Specifications:

- Elastic straps secure cushion to balance board
- Machine washable cover
- Soft, plush interior
- Use with any type of Wii Balance Board game (standing or sitting)

Compatible with all Wii Balance Board games including:

Wii™ Fit Plus
Wii™ Fit
Shaun White Snowboarding World Stage
Rayman Raving Rabbids TV Party
Jillian Michaels Fitness
Super Monkey Ball Step & Roll

CTA Digital, Inc. 49 South Second Street, Brooklyn, New York 11211
Tel. (718) 963-9845 | Toll Free (888) 733-4448 | Fax. (718) 384-3509

www.ctadigital.com